



Lenovo IdeaPad S10-2 Battery Replacement

Replacing the defective battery on your Lenovo IdeaPad S10-2 will allow your laptop to charge and turn on.

Written By: Faylin Riemer



INTRODUCTION

No tools are needed to replace the battery.

Step 1 — Battery



- Start with the laptop upside down and the bottom panel facing up.
- These two switches are used to remove the battery.

Step 2



- Firmly push the two switches inward and toward each other.
- When you push up on the battery it will come out of its port.

Step 3



- Remove the battery.
- ★ To attach the new battery, push the battery back in the correct spot on the computer. You will hear a click once the battery is in place.