




Telstra Dave 4G ZTE T83 Back Speaker Replacement


Written By: Ryan



TOOLS:


Pro Tech Toolkit (1)

Step 1 — Outer Case



- Remove the four H2 screws from the back of the phone. Do not lose the black rubber rings on the screws.
- Remove the two H2 screws, on either side of the phone. Do not lose the red seal that are on the screws.
- Using a prying tool work off the back of the case. Ensuring not to lose the port covers. Be careful to note the position of connector covers. Have the tabs at the end of the connectors in place before clipping the phone completely back together.

Step 2 — Battery Connector Cover




- Remove the two black Philips head screws from the battery connector cover.
- Lift the battery cover away from the logic board

Step 3 — Battery



- Disconnect the battery connector from the logic board. Do so by inserting a flat tool under the wires on the indicated side and wedging it up off the logic board.
- Then remove the double sided tape using the blue tabs provided. Simply grab a tab and pull until it comes out [tweezers](#) are really good for beginning the process.
- ① These pull tabs will need to be replaced with double sided tape on reassembly.

Step 4 — Speaker



- Remove two black Phillips head screws and remove the back speaker assembly.

To reassemble your device, follow these instructions in reverse order.