



Photive Rain Back Panel Replacement

Use this guide to remove the back panel of the...

Written By: abcdef ghijk



INTRODUCTION

Use this guide to remove the back panel of the Photive Rain. Removing the back panel is necessary to access any of the speaker's internal components.

TOOLS:

Tournevis cruciforme #1 (1)

Step 1 — Back Panel



- ① Turn the speaker off before disassembling.
- Remove the suction cup from its groove by twisting and turning it.

Step 2



- Remove the four 8.5 mm screws from the back panel of the speaker by using the Phillips #1 Screwdriver.
- Remove back panel

To reassemble your device, follow these instructions in reverse order.