



# Bosch PS21 Battery Replacement

Replace the battery in your Bosch PS21.

Written By: Lillie Wolter



## INTRODUCTION

Use this guide to replace the battery in the Bosch PS21.

---

### TOOLS:

- [T8 Torx Screwdriver](#) (1)
  - [Small Needle Nose Pliers](#) (1)
  - [Tweezers](#) (1)
  - [iFixit Opening Picks set of 6](#) (1)
  - [64 Bit Driver Kit](#) (1)
-

## Step 1 — Battery



- Pinch the two release tabs on the sides of the battery, and slide the battery out.

To reassemble your device, follow these instructions in reverse order.