



Keurig K40 Handle Replacement

This repair guide will replace the handle on a Keurig K40.

Written By: Andrew Bornemann



INTRODUCTION

This repair guide will demonstrate a way to remove and replace the handle on a Keurig K40.



TOOLS:

- [T15 Torx Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Handle



- Unscrew one of the 2mm screws on the handle using a T15 screw head. Keep a firm grip on the device so it does not shift out of place.

Step 2



- Flip the Keurig over and unscrew the other 2mm screw using the same screw head. Keep a firm grip on the device to prevent it from shifting or falling.

Step 3



- Remove the lever by pulling it away from the Keurig.
- Replace a new handle by putting the Keurig back together the same way it was taken apart.

To reassemble your device, follow these instructions in reverse order.