



# Remove the Front Cover

This will show you how to remove the front cover.

Written By: Paulina Trujillo



# INTRODUCTION

This will show you how to remove the front cover.

## Step 1 — Remove the Front Cover



- Lay Palm IIIc face-up and remove the front cover.
- ⓘ Do this firmly but not with too much force so as to not break or disturb anything you're not supposed to.

To reassemble your device, follow these instructions in reverse order.