



Cambridge SoundWorks OontZ Angle Plus Rubber Casing Replacement

Replacing the soft casing covering the edges of the Cambridge SoundWorks OontZ Angle Plus.

Written By: Farshad Mohebban



Step 1 — Rubber Casing



- Remove the six screw covers from the bottom of the device.

Step 2



- Starting from the screw covers, remove the front and back casing of the device.

Step 3



- Carefully pull off the casing covering the ends.

Step 4



- Slowly remove the casing from the top of the device.

To reassemble your device, follow these instructions in reverse order.