

LG G Stylo Motherboard Replacement

This prerequisite guide contains the information to walk someone through the replacement of the motherboard of the LG G Stylo.

Written By: Alessandro Di Bella



INTRODUCTION

If you are experiencing hardware issues or water damage to the overall phone. You can replace the motherboard and fix your LG G Stylo without buying a replacement.



TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)

Step 1 — Battery





- Make sure that you power off the phone before beginning.
- Remove the back cover by placing the plastic opening tool on the bottom left side of the device and gently prying up.
- (i) There is a small slit that fits the plastic opening tool perfectly on the left side.

Step 2





 Insert the plastic opening tool into the indent at the bottom of the battery and lift up. Fully remove the battery with your fingers.

Step 3 — Motherboard





 Carefully use the Phillips #00 screwdriver to remove the eleven 3.9mm visible screws found on the back. The screws to be removed are marked with the given indicators.

Step 4








- When you have finished removing all of the screws, place the plastic opening tool in the groove at the bottom left corner of the motherboard cover and lift up.
- Make sure to remove the SIM card before you remove the motherboard cover. You can get the cover off without doing this, but the SIM card will be stuck underneath the cover once you put it back together.
- it releases.
- Once a clip is released, you can detach the motherboard cover with your fingers and set aside.

Step 5







- Carefully place the plastic opening tool under the ribbons where the cables are connecting and lift up to detach the cables.
- Keep in mind to be careful with the ribbons, because they are small components and important for the device's functionality.
- (i) The third photo attached depicts what the ribbons look like when they are successfully detached.

Step 6





- Fully remove the motherboard by prying upward with the plastic opening tool.
- (i) This step will be quite simple if all the ribbons have been detached correctly.

To reassemble your device, follow these instructions in reverse order.