



Canon Vixia HF R600 Handstrap Replacement

Replace your camera's hand-strap with this guide; this will also show how to adjust the strap to better fit your hand.

Written By: Logan Coats



INTRODUCTION

If you're using your camera for any extended period of time, you want to have a strap that fits comfortably and securely to help with steady filming. The strap is quite easy to adjust and even replace with a different strap.

Step 1 — Handstrap



- Pull up the Velcro strap starting from the front of the camera and working your way towards the back.
- ⓘ If you are adjusting the hand-strap, tighten or loosen the Velcro strap accordingly and reattach it.
- To remove the hand-strap, pull the Velcro strip through the leather pad.

Step 2



- Remove the strap from the camera body.

To reassemble your device, follow these instructions in reverse order.