



# DeWalt DW920 Battery Replacement

If your battery will not charge there may be a few issues with either the battery pack or the charging station.

Written By: Stephen Rada



## INTRODUCTION

For this guide you will not need any additional tools. By following the basic steps you should be able to remove the battery so a new functioning one can be installed.

## Step 1 — Battery



- Firmly grip the handle of the drill with one hand and the battery with the other.

## Step 2



- Using the hand holding the battery press the two tabs that are located on the left and right side of the battery where it connects to the drill.

### Step 3



- With the two tabs pushed in pull the battery out of the drill.

To reassemble your device, follow these instructions in reverse order.