

Pentax Optio WG-2 Battery Replacement

Replace the battery of your Pentax Optio WG-2.

Written By: Matthew Bessette



INTRODUCTION

Use this guide to replace the battery of your Pentax Optio WG-2.



• Fingers (1)

Step 1 — Battery







If you look on the bottom of the camera you will see a "bump" and in the center of said bump there is a small tab. Simply move the tab and push away from the camera.

Step 2



 Now that the tab is open, look inside to see a label (yellow in picture).
Simply line up the signs (+ T -) with the battery and slide in. To close the lid just push down and slide it the opposite way in step one.

To reassemble your device, follow these instructions in reverse order.