



Sony Ericsson W580i Front Cover Replacement

Replace the front cover or front keyboard.

Written By: Diego



INTRODUCTION

Use this guide to replace the front cover or front keyboard.



TOOLS:

- [iFixit Opening Tools](#) (1)



PARTS:

- [Sony Ericsson W580i Front Cover](#) (1)
- [Sony Ericsson W580i Front Keypad](#) (1)

Step 1 — Front Cover



- Insert the edge of an opening tool between the front cover and the phone.
- Gently pry off the front cover working your way around the edges.

Step 2



- Pull the front cover down and away from the phone.

⚠ The front keypads might come off with the front cover. Do not lose these.

Step 3



- Gently peel the keypad away from the phone.

To reassemble your device, follow these instructions in reverse order.