



Toshiba Satellite L675D-S7016 Battery Replacement

This guide will show you how to properly remove your old battery and install a new one.

Written By: Christopher Antoun



INTRODUCTION

This quick step is the precursor to the other guides.

Step 1 — Battery



- Power down the computer and unplug the power adapter.

Step 2



- Flip the laptop upside down. Locate the two latches on both sides of the battery.

Step 3



- Slide the latch on the right outwards, releasing the lock. The latch stays unlocked once moved.
- Simultaneously slide the latch on the left outwards while pulling the battery towards you.

 Do not touch the metal connectors on the laptop and the battery.

To reassemble your device, follow the steps in reverse order.