



Motorola Entice w766 Battery Replacement

If you are having an issue with changing your battery follow the steps listed below.

Written By: Aalan Miranda



INTRODUCTION

This is a simple guide to help remove the back casing of the device and the battery.

Step 1 — Battery



- Slide the tab off the back of the device.

Step 2



- Use the tab located at the top of the battery to release the battery.

To reassemble your device, follow these instructions in reverse order.