



Roku 3 Remote Control Battery Replacement

Replace the two AA batteries of your Roku 3 remote to restore power.

Written By: Isobelle Espiritu



INTRODUCTION

If your Roku 3 remote has no power, this guide will help you replace the battery.



PARTS:

- [AA Batteries](#) (2)
-

Step 1 — Remote Control Battery



- Flip the remote over so that the buttons are facing down and the end with the wrist strap is nearest your right hand.

Step 2



- Press and hold the black tab above the battery compartment.
- While holding down the tab with your left hand, slide down the battery compartment cover with your right hand to remove it.

Step 3



- Remove the batteries by placing a finger on one end of the battery and pushing downward while pulling the battery out.

To reassemble your device, follow these instructions in reverse order.