

Boosted Board 1st Generation Rear Wheels Replacement

How to take off and replace the rear wheels on your Boosted Board 1st Generation.

Written By: Emily Imfeld



This document was generated on 2020-11-15 11:33:49 PM (MST).

INTRODUCTION

This guide will help teach you how to take off the rear wheels of your Boosted Board.



TOOLS:

- 1/2" Socket Wrench (1)
- 9/64" Allen Wrench (1)

Step 1 — Rear Wheels





- Loosen the two 16.74 mm motor mount hex nut screws with a 9/64" Allen wrench.
- (i) Do Not Remove the Screws.

Step 2



- Compress the motor mount back towards the wheel.
- While keeping the motor mount compressed, tighten one of the hex nuts that you loosened in the previous step.
- The motor mounts are spring tensioned so it is necessary compress them to loosen the belts.

Step 3





Remove the axel nut with a 1/2" socket wrench

Step 4







- Rotate and pull counterclockwise until the wheel comes off the axle completely.
- The front washer will come off with the wheel.
- Remove the back washer from the axle.
- (i) Replacing the wheel requires the bearings to be switched into the new wheel.

To reassemble your device, follow these instructions in reverse order.