

Moto G4 Plus Fingerprint Sanner Replacement

This video shows how to replace a damaged fingerprint scanner.

Written By: Witrigs



INTRODUCTION

[video: https://youtu.be/akY6zX0wrxU]

1. Why you need this video?

The fingerprint scanner of your Moto G4 Plus can get broken or ineffective because of unsuitable operation, scratch and crash. You need to remove the LCD screen first. It is difficult and complicated to separate LCD screen and touch screen when you want to repair each of them. Here is the best solution to replace the broken or unresponsive navigation button of your Moto G4 Plus.

2. What problems does the video solve?

Follow this video to repair the fingerprint sensor of your Moto G(4th) in below conditions:

The navigation button is unresponsive, scratched, broken;

The fingerprint scanner button of G4 Plus doesn't work;

The fingerprint sensor is unresponsive to unlock your phone;

There is something wrong with fingerprint scanner;

Get problem with navigation button;

Fingerprint scanner could't unlock your phone;

The fingerprint scanner is not sensitive enough to unlock your smart phone;

We will upload other repair guide of Moto G4 Plus as soon as possible. Tell us which part of G4 Plus you want to repair at comments section.



TOOLS:

- Heat Gun (1)
- Spudger (1)
- T3 Torx Screwdriver (1)
- Tweezers (1)
- iFixit Opening Tools (1)
- Playing cards (1)



PARTS:

- Fingerprint scanner flex for Moto G4 Plus
 (1)
- Moto G4 Plus Screen Adhesive (1)

To reassemble your device, follow these instructions in reverse order.