



# Gateway LT2514u Battery Replacement

Use this guide to replace the battery on the Gateway LT2514u.

Written By: Brian Garver



---

## INTRODUCTION

This guide will walk you through the process of replacing a dead or dying battery in a Gateway LT2514u.

---



### TOOLS:

- [Tweezers](#) (1)
-

## Step 1 — Battery



- With the netbook's lid closed, flip it over and slide the latch on the upper left hand side of the netbook to the left.
- ⓘ You should see an orange indicator when the battery is unlocked.

## Step 2



- In the upper right-hand corner of the netbook, slide and hold the switch to the right.
- Use your other hand to slide out the battery.
- ❗ If the release switch in the upper right-hand area is missing, you can still remove the battery by following Step 3. Otherwise, skip it.

## Step 3



- If the release switch in the upper right-hand area is missing, insert a slender tool (we used tweezers) into the left side of the smaller hole.
- Slide and hold the tweezers to the right and use your other hand to slide the battery out.



To reassemble your device, follow these instructions in reverse order.