



ASUS U52F-BBG6 CD Drive Replacement

Replace a faulty CD drive in a few easy steps!

Written By: Ashley DeHuff



INTRODUCTION

This guide will show you how to replace your CD compartment. You will need to use the J1 screwdriver in this guide.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [JIS #1](#) (1)
-

Step 1 — Compact Disk (CD) Drive



- Turn the laptop over to the back.
- Unscrew the two 3mm Phillips screws with the PH0 screwdriver.
- Lift the small black panel up and out.

Step 2



- Unscrew the two 3mm Phillips screws with the J1 screwdriver.
- ❗ One 3mm Phillips screw is found inside the compartment.

Step 3



- Tug the CD compartment with your left hand outward.

To reassemble your device, follow these instructions in reverse order.