



Panasonic KX-TG6021M Battery Replacement

This guide will show you how to remove and replace the battery in the Panasonic KX-TG6021M.

Written By: You Zhou



INTRODUCTION

This guide will show you how to remove and replace the battery in the Panasonic KX-TG6021M.

Step 1 — Battery



- Slide the back cover down towards the bottom of the phone to remove.

Step 2



- Pull the top of the battery towards you to remove it from the phone.

To reassemble your device, follow these instructions in reverse order.