



Acer Iconia Tab 8 A1-840 Battery Replacement

Replace the defective or dying battery to restore power to your device.

Written By: Claire Posadas





TOOLS:

- [Heavy-Duty Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Back Panel



- Power off the device
- Remove any cables that might be connected to your device
- Make sure the device is placed on a flat surface with the display screen facing up

Step 2



- Wedge the plastic opening tool in between the display screen and back panel
- ⚠ Do not apply too much pressure in order to avoid cracking the screen

Step 3



- Carefully separate the display from the back panel

Step 4 — Battery



- Use your fingers to pull back and remove the yellow plastic tape covering the battery cable.

Step 5



- Use the flat end of the spudger to pry up and remove the battery cable.

Step 6



- Use the flat side of the heavy duty spudger to lift the small black plastic flap.

Step 7



- Use fingers to pull the Zero Insertion Force (ZIF) cable from the motherboard.

Step 8



- Use fingers to remove the smaller adjacent ZIF cable from the motherboard.

Step 9



- Use the flat end of the spudger to pry the battery up from all edges, and remove it from the back panel.
- ⓘ There is adhesive behind the battery that holds it in place. Be sure to pry slowly and carefully when removing the battery.

To reassemble your device, follow these instructions in reverse order.