



Fujifilm FinePix XP80 Battery Replacement

Removal of the battery from a Fujifilm FinePix XP80.

Written By: Busra Atalay



INTRODUCTION

In this guide, you will learn step-by-step instructions on how to remove the Fujifilm FinePix XP80's battery, whether it's for recharging or replacing this component, this guide will get you there.

Step 1 — Battery



- Open the side panel which houses the battery compartment. Press the center button down and twist the dial.

Step 2



- Release the battery from its secured position by pulling the orange tab back. The battery can then be removed from its compartment.

To reassemble your device, follow these instructions in reverse order.