



# Acer Iconia Tab 8 A1-840 Rear Camera Replacement

This easy how-to guide will detail the removal of the rear facing camera on your Acer Tablet.

Written By: Steven Gontarz



---

## INTRODUCTION

The camera is one the simplest components to replace once the back cover is removed. The important thing to remember here is to take your time removing the cover.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Heavy-Duty Spudger](#) (1)
  - [Precision Tweezers Set](#) (1)
-

## Step 1 — Back Panel



- Power off the device
- Remove any cables that might be connected to your device
- Make sure the device is placed on a flat surface with the display screen facing up

## Step 2



- Wedge the plastic opening tool in between the display screen and back panel
- ⚠ Do not apply too much pressure in order to avoid cracking the screen

## Step 3



- Carefully separate the display from the back panel

## Step 4 — Rear Camera



- Use the flat end of the spudger to gently open the black flap.



## Step 5



- Use the precision tweezers to carefully pull out the connector and remove the camera.

To reassemble your device, follow these instructions in reverse order.