



Motorola Buzz ic502 Battery Replacement

This guide will show the user how to remove and replace the phones battery

Written By: Sarah



INTRODUCTION

This will teach the user where the battery is and how to remove it. No tools will be needed. Make sure to be careful so as not to break anything.

Step 1 — Battery



- First flip the phone over.
- Then find the back release circled in red.

Step 2



- Carefully remove the back using the release.
- Lift from the bottom!

Step 3



- Lift the battery from the right side.
- After the battery has lifted about a 45 degree angle remove from phone.

To reassemble your device, follow these instructions in reverse order.