

## **Dell Inspiron Mini 10 Battery Replacement**

The battery is a source of power for the device.

Written By: Danielle Jarecki



## **INTRODUCTION**

This guide will show you how to remove the battery. This might be a necessary step in replacing a faulty battery or as a safety precaution before working on any other elements of the device.

## Step 1 — Battery



- To prevent injury and loss of data, ensure the device is turned off.
  - Slide the release latches out toward the edges to unlock the battery.

## Step 2



 Remove the battery by pulling it up and out.

To reassemble your device, follow these instructions in reverse order.