



# Dell Inspiron M5110 Battery Replacement

Written By: Cody Flynn





## PARTS:

Dell DL-I13R Battery (1)

### Step 1 — Battery



- Shut down the computer and turn it upside down.

### Step 2



- Slide both of the battery release latches on the bottom of the device in towards the center of the computer.

### Step 3



- Slide and lift the battery up and out from the device.

To reassemble your device, follow these instructions in reverse order.