



HP Pavilion dv4000 Battery Replacement

This guide will show you how to unlock and remove the battery.

Written By: Ashukang Kima Tabong



INTRODUCTION

Removing the battery from your laptop is the first thing you should do before doing any repairs on it. Working while the battery is in the machine might cause damage to the circuit boards or shock you.

Step 1 — Battery



- Turn the laptop upside down with the battery compartment facing you.

Step 2



- Slide the battery release latch to the right and hold in place.

Step 3



- Lift the front edge of the battery up and remove it from the compartment.

To reassemble your device, follow these instructions in reverse order.