


# **Motherboard Replacement**

This task requires the removal of small screws....

Written By: Connor Fisher



#### INTRODUCTION

This task requires the removal of small screws. Be sure you have a secure place to keep the screws such as a magnetic mat.

#### TOOLS:

Desoldering Braid (1)

Lead-Free Solder (1)

Staples (1)

iFixit Opening Tool (1)

Soldering Iron (1)

Spudger (1)

iFixit Precision 4 mm Screwdriver Bit / Nut

**Driver 2.5 mm (1)** 

#### Step 1 — Back Cover








- Insert the plastic opening tool into the middle of the bottom edge of the device. The tool should be inserted within the seam between the back and front covers.
- Slide the opening tool to the right and slowly continue to separate the back cover from the device.


Avoid prying on the buttons, as they are easily damaged.

# Step 2



 Pull the cover off of the device once about three quarters of the cover has been pried open using the plastic opening tool.

# Step 3 — Battery



 Remove masking tape from the battery.

# Step 4



• Pry the battery from the base using the nylon spudger and move it away from the motherboard.

⚠ Handle the battery with care to avoid damaging it.


# Step 5




- De-solder the three contact points and remove the battery.
- ② See the following guide for instructions on how to solder. How To Solder and Desolder Connections

 $\triangle$  Use caution when operating the soldering iron.

#### Step 6 — Motherboard








- Remove the two ZIF connectors attached to the motherboard by flipping up the black tabs before pulling the ribbon cable away.
- ⚠ Only use a fingernail or nylon spudger to flip up the retaining flap. Using metal tools may damage delicate components.

#### Step 7



 Use the nut driver and J00 bit to remove the three 4 mm screws.

# Step 8







- Peel back metal tape that is hiding the auxiliary port wires.
- Remove tape that is holding the speaker wires in place.
- Lift up on the motherboard to release it from the tablet.

To reassemble your device, follow these instructions in reverse order.