



HP Mini 110-3131dx Back Cover Replacement

Removing the back cover of HP Mini 110-3131dx.

Written By: aarondcollege



Step 1 — Battery



- Power off the laptop before trying to remove the battery.
- Turn the laptop upside down, and locate the sliding tabs on the battery.
- Slide both tabs in an inward direction, then slide the battery away from the laptop.

Step 2 — Back Cover



- To remove the bottom cover pull the orange tab to the right until it clicks.
- Carefully disconnect the clips as you lift the bottom cover.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2022-03-20 11:15:25 PM (MST).

