



# Dell Chromebook 11 CB1C13 Special Key Replacement

Written By: Jon



---

## 🔧 TOOLS:

[Tweezers](#) (1)

## ⚙️ PARTS:

[Dell Chromebook Palmrest WR67C \(replacement keys\)](#) (1)


---

### Step 1 — Check Metal Clips & Rubber Spring/Membrane for Damage




- Unlike letter and number keys, some "special keys" have 2 sets of metal clips. Plus, a stabilizer holder on both sides.
- If you notice that one of the metal clips or stabilizer holders is bent, carefully use your [tweezers](#) to bend back into an upright position.

## Step 2 — Check Plastic Brackets



- Check the plastic brackets for damage in these areas.


## Step 3 — Check Key for damage



- Check the 8 main points of the key on the inside of the key for damage.
- Check to make sure the stabilizer (bar) is present and the 3 clips that secure it to the key are not damaged.
- Any damage in these areas will not allow the key to stay connected to the plastic bracket which sits underneath the key.




## Step 4 — Remove Key from old Palmrest



- While using tweezers, remove just the actual key (top layer only) . You want to try and remove the key without also removing the plastic bracket that sits right underneath the key.
- Try to slightly pick at the corner of the key. This helps remove the key separately from the plastic bracket.
- Don't forget that these "special keys" have a stabilizer (bar) underneath the key.

## Step 5 — Remove Plastic Brackets from old Palmrest



- With tweezers, carefully start picking near the four corners where the 4 metal clips are securing the plastic bracket. Remember these special keys have 2 plastic brackets to remove.

## Step 6 — Replace Plastic Brackets on Chromebook



- Line up the 2 outer corners and the bottom inner corners of the plastic bracket with the 4 metal clips connected to the palmrest.
- Repeat this step as there are 2 plastic brackets for both shift keys, spacebar, and Alt key (left of spacebar).

## Step 7 — Replace Key on Chromebook



- First line up the stabilizer ends with the stabilizer holders and slide each end through the stabilizer holders connected to the palmrest.
- Place the key on top of the plastic bracket and press down. If both plastic brackets are on correctly and securely, the key should easily snap into place.
- Check if the key is secure by tapping around all sides of the key. This is a good test to make sure the metal clips are properly securing the plastic bracket, the stabilizer, and making sure that the plastic bracket can hold the key correctly.

---

To reassemble your device, follow these instructions in reverse order.