



# PlayStation 3 Slim Disassembly and Bluray Laser Replacement

Disassembling the PS3 Slim CECH-2501A and...

Written By: Steve Baker



# INTRODUCTION

Disassembling the PS3 Slim CECH-2501A and replacing the Bluray Laser Lens

---



## TOOLS:

[Essential Electronics Toolkit](#) (1)



## PARTS:

[Sony PlayStation 3 Slim Blu-ray Disc Drive \(KEM-450EAA\)](#) (1)

[Sony PlayStation 3 Slim Blu-ray Disc Drive \(KEM-450DAA\)](#) (1)

[Sony PlayStation 3 Slim Blu-ray Disc Drive \(KEM-450AAA\)](#) (1)

---

To reassemble your device, follow these instructions in reverse order.