



PlayStation 4 Pro Hard Drive Replacement

Replace the stock hard drive in the PS4 Pro with a larger-capacity 2.5" hard drive or faster SSD.

Written By: Ronnie



 **TOOLS:**

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Hard Drive Cover



- Start by flipping the PS4 Pro over its top.
- Remove the plastic panel covering the drive bay, using the tab next to the Ethernet port.

Step 2 — Hard Drive Caddy



- Remove the Phillips #0 screw securing the hard drive caddy to the chassis.

Step 3 — Hard drive



- Slide the hard drive caddy out.
- Remove the four Phillips #0 screws securing the hard drive to the caddy.

To reassemble your device, follow these instructions in reverse order.