



Sony Alpha ILCE-6000 Battery Replacement

Written By: Yirga Yilma



INTRODUCTION

If your Sony Alpha ILCE-6000 wont turn on, the battery may be the issue and this guide will help you access and remove the battery.

Step 1 — Battery Replacement



- Turn off the camera by sliding the power switch to OFF.

Step 2



- Flip the camera upside down and locate the battery compartment.
- Slide the compartment lock to OPEN to unlock it.

Step 3



- Locate the blue lever that keeps the battery in place.
- Push the blue lever back to release battery.

Step 4



- Once the battery is free, you are able to take the battery out of the compartment.

The battery can now be replaced the battery with a new and fully charged one.