

Sony Alpha ILCE-6000 Lens Replacement

This guide will help you replacement Sony Alpha 6000 lens when it is damaged or when you want to use a different kind of attachment lens.

Written By: Vuong Nguyen



Step 1 — Lens



 Turn of camera by turning the switch to OFF.

Step 2



 Use the finger, press and hold the release black circle button (on the bottom) next to the lens on the front of the camera.

Step 3





- Using the left hand or the right hand to hold the camera body, other hand twist the lens counterclockwise and pull it off.
- Align the white dot of the lens to the white dot on the camera mount to completely replace.

To reassemble your device, follow these instructions in reverse order.