



Samsung Galaxy - S Display Assembly Replacement

Samsung Galaxy S i9000 How to disassemble and replace LCD Display and fix Home button.

Written By: ZFix



INTRODUCTION

Galaxy S i9000: How to disassemble, LCD Display Touch screen assembly replacement, and home button problem fix.

[video: <https://www.youtube.com/watch?v=DHmEST3S1BE>]

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

To reassemble your device, follow these instructions in reverse order.