



Razer BlackWidow Chroma Padding Replacement

This guide will help consumers replace the padding on the bottom of the keyboard.

Written By: _daemienz@uw.edu



INTRODUCTION

The padding underneath the keyboard is required to prevent movement. Thus allowing the keyboard to be used without discomforting the user. Replacing the padding is needed every now and then to prevent movement and discomfort. The replacement is quite easy to do, with no previous knowledge required.

Step 1 — Padding



- Turn the keyboard over, so that the keys are facing down.
- ⓘ There are 3 pieces of padding at the bottom of the keyboard.

Step 2



- Gently pull back the padding with your fingers.

To reassemble your device, follow these instructions in reverse order.