



Dyson DC28 Animal Post/Pre Filter Assemblies Replacement

Remove the vacuum's filters to be cleaned or replaced as needed.

Written By: Quentin Klueter



INTRODUCTION

No tools or skills are needed to remove the filters. This is one of the most basic and useful replacements when dealing with these vacuums.

Step 1 — Post/Pre Filter Assemblies



- Find and press firmly on the red button located above the dust chamber.
- Hold the handle and pull away from the vacuum base when the button releases the dust chamber.
- Set off to the side.

Step 2



- Find and firmly press the purple buttons on each side of the pre filter assembly.
- When the button releases the filter and its casing, lift straight out of vacuum base.
- After removing the filter in its casing, hold the case with one hand while gently prying the filter out with your other hand.

This document was generated on 2020-11-19 06:45:21 PM (MST).

Step 3



- Find the tab for the post filter cap and pull away from base of vacuum to release the top.
- When the cap has been swung out of the way, pry the post filter out gently (using same technique as before with pre filter).

To reassemble your device, follow these instructions in reverse order.