



Acer Aspire 5517-1127 Battery Replacement

Replace battery to allow a charge to the Acer Aspire 5517-1127 laptop.

Written By: Christopher Abrams



INTRODUCTION

This guide will walk you through how to replace a broken or damaged battery on your Acer Aspire 5517-1127 laptop. If your device does not power on, shuts off, or will not charge, this guide may be able to assist you.

Step 1 — Battery



- Orient the laptop so that it is upside down facing away from you. The battery is at the bottom.

Step 2



- The smaller switch is on the left. Move it to the unlock position.

Step 3



- Once unlocked, move the larger switch on the right to the left to release the battery.

Step 4



- When the switch is moved to the left, the battery will pop up and become removable.

To reassemble your device, follow these instructions in reverse order.