



Protocol Dronium Two Rotor Blade Replacement

This guide is for removing the Protocol Dronium Two Rotor Blade

Written By: Edwin Brietz



INTRODUCTION

This guide is for replacing the Protocol Dronium Two. Included in your box should be four replacement blades. Do this repair in a clean and well lit place because the rotor blade screw is very small and easy to lose.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [Rotor Blade](#) (1)

Step 1 — Rotor Blade



- Turn off the drone by pushing the selector switch to the left.

Step 2



- Using the Phillips screwdriver included with the drone, carefully remove the 4.02 mm rotor blade screw.
- Once the screw is removed, remove the rotor blade by lifting the blade straight off of the drone

To reassemble your device, follow these instructions in reverse order.