



# Toshiba Satellite P55-A5312 RAM Replacement

This guide will help you replace or upgrade the RAM in your Toshiba Satellite.

Written By: Jordan Kochavi



---

## INTRODUCTION

RAM (Random Active Memory) is a type of computer memory that correlates with how quickly your computer can access information. Your RAM stick can be upgraded and replaced easily. First we will open the back of the laptop. After, we can easily remove and upgrade/replace your RAM.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — RAM



- Remove the bottom cover of your laptop. For instructions on how to do this, visit the [Toshiba Satellite P55-A5312 Back Cover Removal Guide](#)

## Step 2



- Locate the RAM stick in the bottom left hand corner of the laptop.
- Carefully pull apart the plastic tabs that hold the RAM in place with your hands.
- The RAM stick should pop upwards when released correctly.

## Step 3



- Remove the RAM stick and replace it with your new one.

To reassemble your device, follow these instructions in reverse order.