



# 1993–1997 Ford Ranger Oil and Oil Filter Replacement

A video tutorial on how to change the oil and oil filter on your 2.3L Ford Ranger (1994-1997).

Written By: eCuration



## INTRODUCTION

This video guide will show you how to replace the oil and oil filter on your 2.3L OHC I4 Ford Ranger.

[video: [https://www.youtube.com/watch?v=LuWV7c\\_HLD8](https://www.youtube.com/watch?v=LuWV7c_HLD8)]



### TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Oil Drain Pan](#) (1)
- [Oil Filter Wrench](#) (1)
- [Long Neck Funnel](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [13mm Socket](#) (1)
- [3/8-Inch Drive Extension Bar](#) (1)
- [Paper Towels](#) (1)



### PARTS:

- [5W-20 Motor Oil](#) (4)
- [Oil Filter 2.3L OHC I4 Ford Ranger](#) (1)

To reassemble your device, follow these instructions in reverse order.