



Toaster Lever Replacement

How to fix a toaster that won't stay down.

Written By: Sydtracked

INTRODUCTION

How to fix a toaster that won't stay down.

TOOLS:

- [Mahi Driver Kit - 48 Bit Driver Kit](#) (1)
 - [Anti-Static Brush](#) (1)
-

To reassemble your device, follow these instructions in reverse order.