



Written By: Travis Williams



---

## INTRODUCTION

Make sure to keep the processor unplugged during replacement of knob.



### TOOLS:

- [Heavy-Duty Spudger](#) (1)
-

## Step 1 — Power Knob



- Using the heavy duty spudger pry the plastic knob off the front of the processor.

To reassemble your device, follow these instructions in reverse order.