



Fujifilm Finepix S1800 Battery Replacement

Battery Replacement for Fujifilm Finepix S1800 Camera.

Written By: Ryan Rockford



INTRODUCTION

Having trouble getting your Fujifilm FinePix S1800 to turn on? It may be time to change the batteries, this guide will walk you through the steps on how replace the batteries.



TOOLS:

- [No tools required for this replacement.](#) (1)



PARTS:

- [AA batteries of any brand.](#) (1)

Step 1 — Battery



- Turn the camera over and find the switch to open up the battery storage area.
- Push and hold the switch towards the lines. Then pull away from the camera to open up the battery storage area.

Step 2



- Take out the four existing batteries and replace them with four new AA batteries and close the cover.
- ☑ Make sure when putting in the new batteries that the ends alternate from positive, negative, positive again, and then negative again.

To reassemble your device, follow these instructions in reverse order.