




Dell Inspiron E1405 Heat Sink Replacement

This guide will help you replace the heat sink in a Dell Inspiron 1305.

Written By: Sarah Neal Secrest



INTRODUCTION

This guide will help you replace the heat sink in a Dell Inspiron 1305.




TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery



 Save your work, power the laptop off, and ensure that the charging cable is unplugged before removing the battery.


- Flip the laptop over.
- Locate the battery release switch on the bottom of the laptop.

Step 2




- Slide the battery release switch away from the lock symbol until you hear the battery click.
- Slide the battery towards the back of the laptop until it comes free.

Step 3 — Heat Sink



- Remove/loosen the eight 4.8mm screws with a #1 Phillips screwdriver securing the bottom panel.
- Remove the bottom panel.

Step 4



- Loosen the five 5.5mm screws with a #1 Phillips screwdriver securing the heat sink and clean it with compressed air
- Gently lift the heat sink from the side, as indicated in the picture.

To reassemble your device, follow these instructions in reverse order.