



How to Drain and Refill Coolant 2004-2008

Audi A4 (B7)

A video tutorial on how to check and refill the engine coolant level on a 2004-2008 Audi A4 (B7)

Written By: eCuration



INTRODUCTION

Changing and flushing your engine coolant is about a once-every-two-years maintenance task. It's a straightforward job in many ways, but following this short video guide will show you how to do it on a 2004-2008 Audi A4.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Flathead Screwdriver](#) (1)
- [Slip Joint Pliers](#) (1)



PARTS:

- [Engine Coolant](#) (1)

To reassemble your device, follow these instructions in reverse order.