




How to Lenovo Tab 2 A7-10 Error: PMT changed for this ROM it must be downloaded - solution

How to Lenovo Tab 2 A7-10 Error: PMT changed for this ROM it must be downloaded solution

Written By: ZFix



<input checked="" type="checkbox"/>	Name	Begin Address	End Address	Region	Location
<input checked="" type="checkbox"/>	PRELOADER	0x0000000000000000	0x000000000001c31f	EMMC_BOOT_1	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\preloader_adaml.bin
<input checked="" type="checkbox"/>	MBR	0x0000000000000000	0x000000000000001f	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\MBR
<input checked="" type="checkbox"/>	EBR1	0x0000000000000000	0x000000000000000f	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\EBR1
<input checked="" type="checkbox"/>	UBOOT	0x000000000001420000	0x0000000000000000		E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\uboot.bin
<input checked="" type="checkbox"/>	BOOTIMG	0x000000000001480000	0x0000000000000000		E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\boot.img
<input checked="" type="checkbox"/>	RECOVERY	0x000000000001480000	0x0000000000000000		E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\recovery.img
<input checked="" type="checkbox"/>	SEC_RO	0x000000000001480000	0x0000000000000000		E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\secro.img
<input checked="" type="checkbox"/>	LOGO	0x000000000004000000	0x0000000000043837	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\logo.bin
<input checked="" type="checkbox"/>	TEE1	0x000000000005100000	0x0000000000051892ff	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\tee1.img
<input checked="" type="checkbox"/>	TEE2	0x000000000005600000	0x000000000005682ff	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\tee2.img
<input checked="" type="checkbox"/>	ANDROID	0x000000000005600000	0x000000000005682ff	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\system.img
<input checked="" type="checkbox"/>	CACHE	0x000000000005600000	0x000000000005682ff	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\cache.img
<input checked="" type="checkbox"/>	USRDATA	0x000000000005600000	0x000000000005682ff	EMMC_USER	E:\Services\New folder\T2-A7-10F_554_150801_ROW\target_bin\userdata.img



PMT changed for the ROM

INTRODUCTION

MediaTek MT6572 MT6577 MT6582 MT6589 MT6735M

Sometimes when you try flashing stock firmware via SP Flash Tool you get the error. How to fix it.

Error solved

Fixing PMT Changed for the rom

- In SP Flash Tool interface, click Format tab
- Select Format whole flash except Bootloader click Start and reconnect the device.
- When the format procedure finished, go back to to Download tab
- Load scatter file of the firmware you wish to flash click Download and reconnect the device.

[video: <https://www.youtube.com/watch?v=RMOu80AXjvU>]

To reassemble your device, follow these instructions in reverse order.