



# 1993-1997 Toyota Corolla Coolant Replacement

A video tutorial that will show you how to change the old coolant in your 1993-1997 Toyota Corolla.

Written By: eCuration



## INTRODUCTION

You should change the engine coolant once every 2 years.

Follow this video tutorial by YouTuber [NutzAboutbolts](#) to complete this job yourself.



### TOOLS:

- [Oil Drain Pan](#) (1)
- [Long Neck Funnel](#) (1)



### PARTS:

- [Engine Coolant](#) (1)

To reassemble your device, follow these instructions in reverse order.