



2002-2006 Cadillac Escalade Engine Air Filter Replacement

A video tutorial on how to change an old worn out engine air filter on a 2002-2006 Cadillac Escalade.

Written By: eCuration



INTRODUCTION

The engine air filter should be replaced every 30,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the swap yourself.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)



PARTS:

- [Engine Air Filter](#) (1)

To reassemble your device, follow these instructions in reverse order.