



# 2009-2015 Toyota Prius Transmission Fluid Replacement

A video tutorial on how to change the automatic transmission on a 2009-2015 Toyota Prius by drain and refill method.

Written By: eCuration



This document was generated on 2020-11-28 05:59:02 AM (MST).

# INTRODUCTION

The transmission fluid on a Toyota Prius should be drained and refilled every 60,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the job yourself.



## TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stands](#) (1)
- [Wheel Chocks](#) (1)
- [1/2" Drive Breaker Bar](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [3/8-Inch Drive Extension Bar](#) (1)
- [10mm Socket](#) (1)
- [10mm Allen Wrench](#) (1)
- [Fluid Hand Pump](#) (1)
- [Oil Drain Pan](#) (1)
- [Paper Towels](#) (1)
- [WD-40](#) (1)
- [Flathead Screwdriver](#) (1)



## PARTS:

- [Automatic Transmission Fluid 1 qt.](#) (5)
- [Oil Drain Plug Gasket](#) (1)

To reassemble your device, follow these instructions in reverse order.